

Research Area: Image Fusion for Robust Iris Recognition



David Stoker
 Program Manager, Optical Systems
 SRI International


david.stoker@sri.com

650-859-2243

6/10/2013

1. Recognition of Super-resolved Iris


Image Segmented Template



Hamming Distance
 = 0.30908

2. Atmospheric Turbulence Mitigation

Single input frame Fused images Deblur out




2 lp/mm @ 25 meters


Super-resolution methods

Several, noisy blurry frames are fused to produce a low noise, high resolution image !


Low Res Input



Ikena™



SRI



Iris feature size


- Multi-frame image fusion
- Reduces camera artifacts
- Reduces noise
- X4 increase in resolution

...means we can use *faster, lower resolution sensors*
...also a *wider field of view for a fixed resolution!!!*

These are significant advantages with practical applications

For example:

➤ *a single sensor to be used for both face and iris recognition*




Super-resolved Iris Performance



Physical Sciences Division

Hamming Distance Measured at 3 meters, stationary target, superresolved



Super-resolution methods can achieve very good performance for short standoff.
Fair to good performance for > 20 meter standoff.
Ikena software outperforms on Irises, underperforms on targets.

Atmospheric Problems

...are also solvable by image fusion



Physical Sciences Division

Setup: Outdoor path length = 25 meters. Over black top during daylight.




Fig. 4. (Color online) Indoor and outdoor (a) setup, (b) point spread function (measured from corneal glint), and (c) ocular images. PSF, point spread function.

20 March 2013 / Vol. 52, No. 9 / APPLIED OPTICS

Ocular Images were registered using computer-vision derived features (iris perimeter).
Frame weighting was used to remove occlusions from the eyelid.

Conclusions

Results obtained without use of 'special' hardware – just multi-frame image fusion Physical Sciences Division



Before restoration

Indoor-Indoor		Subject		
Subject	A	B	C	
A	0.405	0.468	0.472	
B	0.478	0.365	0.479	
C	0.478	0.468	0.409	

Indoor-Outdoor		Subject		
Subject	A	B	C	
A	0.461	0.479	0.469	
B	0.465	0.448	0.472	
C	0.476	0.482	0.477	

After restoration

Iris Registration		Subject		
Subject	A	B	C	
A	0.298	0.458	0.441	
B	0.440	0.338	0.461	
C	0.469	0.440	0.363	

Glint Registration		Subject		
Subject	A	B	C	
A	0.291	0.451	0.445	
B	0.435	0.366	0.456	
C	0.476	0.442	0.353	

True Positive: < 0.35 (avg)

False Positive: > 0.44 (avg)



1:150,000 chance of false positive

- Direct application of SR doesn't always work, particularly in dynamic video data – proprietary Ikena software better though resolution poorer on fixed targets
- Apparent loss in resolution via image fusion offset by ability to enhance 'subspace' features leading to better recognition contrast
- Atmospheric de-warping may apply to the pose problem for facial recognition by normalizing feature locations

David Stoker
Program Manager,
Optical Systems
SRI International
david.stoker@sri.com
650-859-2243
<http://www.sri.com>